



8" Sleeper depth takes into account 7" from the exterior framing towards the interior and 1" extending past the exterior framing. The 1" extension is needed to support the outer track. 8" sleeper width does not take into account: pans, membranes & sealant provided by others.

Notice: This document contains information proprietary to and is protected by copyright of Win-Dor Inc. and shall not be copied, disclosed to others, or used for any purpose other than that for which it is given, without the written permission of Win-Dor Inc.

**WinDOR**  
www.windorsystems.com

450 Delta Ave  
Brea, Ca 92821  
(714) 385-1202

Project:	File name: 2750 3 Panel Multi Slide - 1 inch Nail-fin - 1.5 inch Sleeper Sill	Date: 20190304
Notes:	Layout: 3 Panel with 1.5 inch Sleeper Sill	Drawn by: J Johnson