



STORM DOOR HOMEOWNER MAINTENANCE AND CARE INSTRUCTIONS

Glass

Clean glass with household glass cleaner or a mixture of warm water and mild detergent using a soft cloth or paper towel.

Door Finish

Painted surfaces can be cleaned using:

- Solution of liquid soap and warm water
- Formula 409, Windex or Fantastik.
- Simple Green or a similar cleaning product.
- Polish with a soft clean cloth.
- **NEVER USE ABRASIVE CLEANERS, THINNERS OR STRIPPERS.**

Hinges and Hardware

Hinges and hardware require lubrication in order to function correctly. Occasionally lubricate with Lithium-based oil or spray lubricant.

Brass Hardware and Deadbolts

Without proper care, brass finishes will tarnish and in extreme neglect, pitting can occur. To clean:

- Wash hardware with warm water and a mild soap using a soft cloth.
- Application of non-abrasive paste wax will help keep finish bright.
- **NEVER USE ABRASIVE CLEANERS, THINNERS OR STRIPPERS.**

Brass or Nickel Expanders

Expanders can be cleaned using a warm water and mild detergent solution and a soft cloth. **NEVER USE BRASS CLEANERS OR STEEL WOOL.**